

USER GUIDE

9CH/16CH MPEG4 Digital Video Recorder

Ver. 2.1




About this user guide

Before installing and using this unit, please read this user guide carefully.

Be sure to keep it handy for later reference.

The specification and information are subject to change without notice for quality improvement.

Safety Precautions



Explanation of Graphical Symbols



This symbol indicates the presence of important operating and maintenance (servicing) instruction in the literature accompanying the product.



This symbol indicates the presence of un-protected "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

Cautions

This product has multiple-rated voltages (110v and 220v).

See installation instructions before connecting to the power supply.

This product uses a Lithium battery.

To avoid of risk of explosion, do not replace the battery on the main board by anything other than a Lithium battery. Dispose of used batteries according to the manufacturer's instructions.

This equipment and all communication wirings are intended for indoor use only.

To reduce the risk of fire or electric shock, do not expose the unit to rain or moisture.

Warnings

Installation and servicing should be performed only by qualified and experienced personnel.

Power off the DVR when connecting cameras, audio or sensor cables.

The manufacturer is not responsible for any damage caused by improper use of the product or failure to follow instructions for the product.

The manufacturer is not responsible for any problems caused by or resulting from the user physically opening the DVR for examination or attempting to fix the unit. The manufacturer may not be held liable for any issues with the unit if the warranty seal is removed.

Rack Mount Instructions

The following or similar rack-mount instructions are included with the installation instructions:

A) Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.

B) Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.














C) Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

D) Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on over current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

E) Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips)."

Product Components


The package contains the main unit and its components as specified below. When you purchase the unit, please check to ensure the components specified below are included.

DVR Set	
CDRW (Option)	
Client Software CD	
Remote Control	
Battery 1.5V (AAA x 2EA)	
User Guide	
IDE HDD Cable 80pin (1EA)	
IDE CDRW Cable 40pin(1EA)-(Option)	
Power Cable	
HDD Brackets (2EA) & Screw (8EA)	
CDRW Bracket(1EA) & CDRW Screw (8EA)	
HDD & CDRW Bracket Screw (12EA)	
Rack Mount (2EA)-(Option) & Screw (6EA)	

Power Cord (110V or 220V)



Video Signal Select & RS-422/485 Settings



Video mode		Video output	
NTSC	PAL	BNC	VGA
T E S T 4 2 V G A P A L 	T E S T 4 2 V G A P A L 	T E S T 4 2 V G A P A L 	T E S T 4 2 V G A P A L
RS-422/485 Select		RS-485 Termination	
485	422	ON	OFF
T E S T 4 2 V G A P A L 	T E S T 4 2 V G A P A L 	T E S T 4 2 V G A P A L 	T E S T 4 2 V G A P A L

NOTICE

1. Do not change the setting when the power is on. When the switch is changed, the DVR should be rebooted to apply the new setting.
2. RS-485 Termination ON/OFF function is available on specific hardware version of the system. Please inquiry the manufacturer.

Compatible HDD Models

Company	Capacity	RPM	Buffer	Interface
HITACHI	80 GB	7200 RPM	2 M	E-IDE
	160 GB	7200 RPM	8 M	E-IDE
	250 GB	7200 RPM	8 M	E-IDE
	500 GB	7200 RPM	8 M	E-IDE
MAXTOR	80 GB	7200 RPM	2 M	E-IDE
	200 GB	7200 RPM	2 M	E-IDE
	250 GB	7200 RPM	8 M	E-IDE
	300 GB	7200 RPM	16 M	E-IDE
SAMSUNG	80 GB	7200 RPM	2 M	E-IDE
	160 GB	7200 RPM	2 M	E-IDE
Western Digital	160 GB	7200 RPM	2 M	E-IDE
	200 GB	7200 RPM	8 M	E-IDE
	250 GB	7200 RPM	8 M	E-IDE
	320 GB	7200 RPM	8 M	E-IDE
SEAGATE	40 GB	7200 RPM	2 M	E-IDE
	80 GB	7200 RPM	2 M	E-IDE
	120 GB	7200 RPM	2 M	E-IDE
	160 GB	7200 RPM	2 M	E-IDE
	300 GB	7200 RPM	8 M	E-IDE
	400 GB	7200 RPM	8 M	E-IDE
	500 GB	7200 RPM	8 M	E-IDE
	750 GB	7200 RPM	8 M	E-IDE

NOTICE

The brands and models of all HDD should be the same. If the brands and models of each HDD


are different with others, the DVR could not recognize HDD.

CDRW Installation Guide

1. Open the top cover of DVR set and Install the CDRW inside the DVR.



2. Fasten the screws on both side of CDRW as indicated in red circle below.



3. Connect the IDE CDRW 40pin cable and Power cable to the point on both CDRW and Main board as indicated in red circle below.




4. CDRW JUMPER SETTING = **MASTER**

Compatible CD-RW model


- LG GCE-8525B / GCE-8526B / GCE-8527B

HDD Installation Guide


1. Unfasten the cover of the unit.



2. Fix the bracket to the hard disk using the supplied HDD mounting bracket screws.



3. Connect the supplied IDE HDD 80pin cable and Power cable to the hard disk and fix the hard disk to the unit the supplied HDD fixing screws.



4. HDD JUMPER SETTING

1ST HDD = MASTER

2nd HDD = SLAVE

Specifications

ITEM			DVR-9CH/16CH
Video	Input	Channel, Input Level	9/16CH, Composite 1.0Vp-p, 75 Ohm
		Signal Format	NTSC/PAL
		Video Loss Check	Yes
	Output	Main Monitor Output	1 CH BNC, 1 CH S-VIDEO, 1CH VGA
		Output Level	Composite 1.0Vp-p +_0.2, 75 Ohm
		Signal Format	NTSC/PAL & VGA
		Etc Output	9/16CH Loop-back , 1CH SPOT
Audio	Input & Output		4 CH Line input & 1 CH Line output
	Audio Codec		G.711
Alarm	Sensor Input		9/16 (NC/NO Selectable)
	Alarm Output		4
	Alarm Output		By Alarm, Motion, Video Loss
Recording	Compression		MPEG-4
	Multi-operation		TRIPLEX (Playback/Record/Network)
	Resolution	NTSC	352x240 704x240

	PAL	704x480	
		352x288	
		704x288	
		704x576	
	Recording quality grade	5 grades	
	Recording Mode	Continuous / Schedule / Motion/ Sensor/ Manual	
	Motion Detection	Motion detection setup by Grid	
	Pre & Post Recording	Yes	
Display			
Frame Rate (/Sec)		NTSC: 30fps/ch, 60 fields / PAL: 25fps/ch, 50 fields	
Playback	Multi-Decoding		1, 4, 9, 16
	Playback Speed	Fast Forward / Reverse	× 2, 4, 8
	Search Mode		Event, Archive, Log
Storage	Internal HDD	Interface Type	EIDE/ATA133
		Capacity of 1 HDD	750GB
		Max HDD Number	2
	File system		NaFS: Own developed & Designed for never broken by any power failure
	Backup	USB 2.0 flash stick	Still Image & AVI
		CDRW	Still Image & AVI
Network		Moving picture & Still Image	
User I/F	Menu Display		GUI
	Input Method		Front Keypad, Remote controller
Serial port	Console & External Modem		1 RS-232C (9pin D-SUB connector)
	Camera control		1 RS-485/422 (4 Terminal Block)
Network	Dynamic IP support		Yes
	Network Interface		10/100 base-T Ethernet (RJ-45)
Network Client S/W	Functions		Live, Search, Backup, PTZF Camera Control
	Central Monitoring System		Yes
Additional Functions	DLS (Day Light Saving)		Yes
	Multi-Language		Yes
	S/W Upgrade		USB 2.0 memory stick
Power	Power Source		100~127V/200~240V, 50-60Hz

Recording performances and resolutions per models

MODEL	Recoding performance (Max.)			
SDVR-9000C	NTSC	352x240: 120fps	704x240: 60fps	704x480: 30fps
	PAL	352x288: 100fps	704x288: 50fps	704x576: 25fps
SDVR-9200C	NTSC	352x240: 240fps	704x240: 120fps	704x480: 60fps
	PAL	352x288: 200fps	704x288: 100fps	704x576: 50fps
SDVR-16000C	NTSC	352x240: 120fps	704x240: 60fps	704x480: 30fps
	PAL	352x288: 100fps	704x288: 50fps	704x576: 25fps
SDVR-16200C	NTSC	352x240: 240fps	704x240: 120fps	704x480: 60fps
	PAL	352x288: 200fps	704x288: 100fps	704x576: 50fps
SDVR-16400C	NTSC	352x240: 480fps	704x240: 240fps	704x480: 120fps
	PAL	352x288: 400fps	704x288: 200fps	704x576: 100fps

Table of Contents

1. Features	15
2. Name, Function and Connection	16
2-1. Front Panel	16
2-2. Rear Panel.....	18
2-3 Remote controller	19
3. Setting up the DVR	20
3-1. Setup – Main Screen	20
3-2. Setup – Display Mode	22
3-3. Setup – Recording Mode.....	23
3-3-1. Quick record setting	25
3-3-2 Recording Schedules	25
3-4. Setup – Device Mode	26
3-4-1. ALARM-OUT	27
3-4-2. SPOT – OUT	28
3-4-3 PTZ Setup	28
3-4-4. Motion Zone Setup	29
3-5. Setup – Storage Mode.....	30

3-6. Setup – System Mode	31
3-7. Setup – PASSWORD Mode	35
3-8. Setup – Network Mode	37
3-8-1. Ports	38
3-8-2. Network Types.....	39
3-8-2-1. LAN	39
3-8-2-2. DHCP	40
3-8-2-3. ADSL (PPPoE)	40
3-8-3. Saving Setup of Network setup	41
3-9. Setup - CONFIG Mode	41
4. Saving Setup	43
5. Live, Search, and Playback.....	44
5-1. Live Viewing Screen	44
5-2. SEARCH Screen	46
5-2-1. TIME-LINE Search	46
5-2-2. Event Search.....	47
5-2-3. Go To First Time	48
5-2-4. Go To Last Time	48
5-2-5. Go To Specific Time.....	48
5-2-6. Log List Search	48
5-2-7. Archive Search	49
5-3. Play mode.....	49
6. PTZ Control	50
7. Backup	51
7-1. Still Image backup onto USB flash memory or CD media	51
7-2. Video backup onto USB flash memory or CD media.....	52
7-3. Transferring still images or video from the ARCHIVE list	53
7-4. Playback of Backup Video.....	53
7-4-1. Playback of backup video in AVI format	53
7-4-2. Playback of backup video in exclusive (NaFs) format.....	54
8. Upgrading Firmware	55
9. Network – By an exclusive viewer.....	56
9-1. Overview.....	56
9-2. Minimum PC requirements	57
9-3. Installing the program	57
9-4. Live viewer.....	58
9-5. Search and Playback Viewer.....	60
9-5-1. Backup	61

9-6. PC System configuration	62
9-6-1. General.....	62
9-6-2. Site	62
9-6-3. Event	63
9-6-4. Record.....	64
9-6-5. Disk	65
10. Network – By an web-browser viewer.....	66
10-1. Download Web Brower Viewer and Connection.....	66
10-2. Main Features.....	67
10-2-1. Live.....	67
10-2-2. Search and Playback	68
APPENDIX.....	69
1. How to register DDNS (Dynamic Domain Name Server)	69
1-1. Setting of NETWORK Setup menu.....	69
1-2. Checking Mac address on the rear panel of DVR and Registration No.	70
1-3. Registration at DDNS.	70
2. Network access using Domain name	72

1. Features

- 9/16 channels real-time live display and 9/16 channels simultaneous playback.
- MPEG-4 - Unbeatable recording picture quality and compression ratio. Best format for minimizing recording space and bandwidth requirements for network transmission.
- TRIPLEX - Simultaneous recording, playback and transmission via network
- NaFS (File System) - Designed to prevent data loss or corruption in the event of a power failure.
- Multiplexing operation
- Reliability - Real Time Operating System and simplified hardware as well as watchdog timer ensure reliability.
- Individual channel recording and playback with different frame rate.
- High-quality live and playback resolution.
- Multi-site management - Supported by CMS application.
- Network features - remote live, playback, PTZF control, and backup.
- Network via LAN, DHCP, ADSL (Dynamic and Static IP address).
- 4 channels audio recording.
- User-friendly setup menu with graphic user interface.
- Easy to schedule complicated weekly recording plans.
- Motion detection – Use the 30x24 grid to define motion zones for each camera.
- USB ports for JPEG, MPEG data backup and software upgrade using USB flash memory stick.
- Still image capture and review as JPEG format.
- Internal Pan/Tilt/Zoom/Focus controller.
- Easy operation with buttons on the front panel and an optional remote control.
- User verification by password certification.
- Video loss detection.
- Backup - Still-images or AVI data into USB flash memory stick, internal CDRW, and Network.
- Variety of Hard Drive Sizes - up to internally **1TB (500GB X 2 HDD)** for long-term recording.
- Multi-Languages -User can easily select language from Setup menu.
- Various Video Output - VGA(800x600 24 Bit Color), S-VHS, SPOT

2. Name, Function and Connection

2-1. Front Panel

The following information will help you to operate the front panel controls.




Figure 2.1.1. Front panel

Table 2.1.1. Indication lamps

NO.	Name	Description
A	HDD	Indicating that the system is accessing the hard disk.
B	RECORD	Indicating that the system is recording video data.
C	ALARM	Indicating that when sensor(s) is/are triggered or motion is detected.
D	NETWORK	Indicating that when Network client connects through the network.
E	BACKUP	Indicating that USB or CDRW storage device is stored images or video.

Table 2.1.2. Front panel buttons

NO	Name	Description
1	POWER	POWER ON/ OFF
2	NUMBER	Channel keys. For channel 10, press the 0 key. For channel 11, press the +10 and 1 key. For channel 16, press the +10 and 6 key.
3	SEQ	Enable/disable the automatic sequence of display of channels in full screen, quad, 9-split display mode.
4	PTZ	Press to control Pan/Tilt/Zoom operations.
5	SETUP	Press to enter SETUP menu.
6	BACKUP	Press to capture video in jpeg format in live or playback mode.
7	REW	Press to rewind the footage in playback mode.
8	AUDIO	Press to select audio mode such as SINGLE, MIX and MUTE. MUTE- All of 4 channels.

		SINGLE- Highlighted channel only. MIX- All of 4 channels.
8	F/REW	Jump/Step backward. In playback mode, the playback position moves 60 seconds backward.
9	ALARM	Press to enable/disable ALARM operation.
9	F/ADV	Jump/Step forward. In playback mode, the playback position moves 60 seconds forward.
10	FF	Press to fast forward the footage in playback mode.
11	REC	Press to start or stop manual recording.
12	SEARCH	Press to go to SEARCH menu in live display mode.
	PLAY/PAUSE	Press to play and pause the footage in playback mode.
13	UP	Press to move up the menu in Setup mode. It is also used as the number 1 when entering password.
14	RIGHT	Press to move right or to change the values in Setup mode. It is also used as the number 2 when entering password.
15	DOWN	Press to move down the menu in Setup mode. It is also used as the number 3 when entering password.
16	LEFT	Press to move left or to change the values in Setup mode. It is also used as the number 4 when entering password.
17	SEL	Press to select desired menu item or to store the setup value.
18	ESC	Press for temporary storage of the changed value or to return to the previous menu screen.
19	USB Port	To archive still-image or video into a USB memory and USB CDW or upgrade firmware with USB memory stick.

2-2. Rear Panel





Figure 2.2.1. Rear Panel

Table 2.2.1. Rear panel connections

NO	Connection	Purpose
1	VIDEO IN	9/16 connectors for video input. (NTSC/PAL)
2	VIDEO OUT	9/16 connectors for video output. (Loop Back)
3	SPOT	Composite video output for spot monitoring.
4	VIDEO	Composite video output in NTSC or PAL format.
5	S-VHS	S-VHS output.
6	VGA	Connector for VGA monitor.
7	AUDIO IN	4 connectors for audio input.
8	AUDIO OUT	1 connector for audio output.
9	RS-232	For engineering use only.
10	LAN	RJ-45 connector for LAN connection.
11	RS-485/422	For camera control use.
12	SENSOR IN	8/16 connectors for sensor device connection.
13	ALARM OUT	4 connectors for alarm device connection. Provides simple On/Off switching by using relay. 0.5A/125V, 1A/30V
14	POWER	Connect AC115/230V power cable.

2-3 Remote controller



POWER	Power On/Off
DISPLAY	Display of Full, Quad or 9 split view
F/REW	Jump 60 seconds backward
PLAY	Play/Pause
F/ADV	Jump 60 seconds forward
FREEZE/CAP	Freeze/Capture
FF	Fast Forward
ALARM	Disable alarm operation
SETUP	Setup menu screen
ARCHIVE	Display archive list
AUDIO	Disable, Mute or Highlighted channel only
LOCK	Locks functions
SEQ	Sequence of Full or Quad view
RECORD	Manual recording
SEARCH	Search menu screen
DIRECTION	Direction or number 1 to 4
SELECT	Enter
ID	DVR ID (ID Button + DVR ID number)
ESC	Esc
PTZ	PTZ menu screen
NUMBER	Channel 1 to 9
+10	Channel 10 and channel 11 to 16 10CH->press +10 and number 0 11CH->press +10 and number 1 12CH->press +10 and number 2 13CH->press +10 and number 3 14CH->press +10 and number 4 15CH->press +10 and number 5 16CH->press +10 and number 6

3. Setting up the DVR

The following sections detail the initial setup of the DVR

3-1. Setup – Main Screen

When the SETUP button is pressed, the DVR will ask for a password. The default password is 1111, which can be entered by pressing the up button 4 times and then pressing the SEL button. It is recommended that a new password be assigned to protect the system. The procedure for assigning a password is found in section 3.7. After a password has been assigned, enter the password by using the direction keys (representing 1, 2, 3, & 4) and press the SEL button for the password validation. Once the password is entered the Setup screen as shown in Figure

3.1.1. will appear. Navigate through the menu items and press the SEL button to enter the sub-category menu.





Figure 3.1.1. Setup screen

Table 3.1.1. Setup menu configuration

DISPLAY	—	OSD
	—	SEQUENCE
	—	SEQ-DWELL TIME
	—	OSD CONTRAST
	—	CHANNEL — DISPLAY, BRIGHTNESS, CONTRAST, HUE, SATURATION
RECORD	—	RESOLUTION
	—	CHANNEL — FRAME RATE, QUALITY, RECORDING, SENSOR RECORDING, PRE RECORD, POST EVENT RECORD, AUDIO, SCHEDULE
DEVICE	—	ALARM OUT
	—	SPOT -OUT
	—	PTZ
	—	CHANNEL — MOTION ZONE, MOTION SENSITIVITY
	—	KEY TONE
	—	REMOTE CONTROL ID
	—	SENSOR — TYPE
STORAGE	—	OVERWRITE
	—	DISK FORMAT
	—	DISK INFO
	—	RECORDING LIMIT
	—	RECORDING LIMIT DAYS



3-2. Setup – Display Mode

To set values for live display, use the UP and DOWN controls to navigate through the menu items. Change the value of the menu item using the LEFT and RIGHT controls.




Figure 3.2.1. Display mode setup screen

Table 3.2.1. Menu items in DISPLAY mode setup

Item	Description
OSD	Enable/disable on-screen-display.
SEQUENCE	Enable/disable sequential display of video in Full Screen mode.
SEQ-DWELL TIME	Set the dwell time for each, 4 or 9 channels display in sequential display mode.
OSD CONTRAST	Set the visibility level of the On Screen Display (OSD).
CHANNEL	Select the channel for applying the following settings. Presses SELECT to change channel name.
DISPLAY	Enable/disable display of the video channel in live display mode
BRIGHTNESS	Change the brightness value for the specified channel.
CONTRAST	Change the contrast value for the specified channel.
HUE	Change the hue value for the specified channel.
SATURATION	Change the saturation value for the specified channel.

3-3. Setup – Recording Mode

To set values for recording video, use the UP and DOWN controls to navigate through the menu items. Change the value of the menu item using the LEFT and RIGHT controls.




Figure 3.3.1. Recording mode setup screen


Table 3.3.1. Menu items in Recording mode setup

Menu item	Description
RESOLUTION	Set the resolution to either 704x480, 704x240, or 352x240 for NTSC. (PAL: 704*576/ 704*288/ 352*288)
CHANNEL	Select the channel to apply the following settings on. Changes you make will immediately take effect with the selected channel.
FRAME RATE	<p>Set the frame rate for the specified channel. The sum of the frame rate values from each channel cannot exceed the maximum frame rates for a specific recording resolution.</p> <p>Typical values of the maximum frame rate for video are</p> <p>120/100 fps version: 120/100fps: 352*240(NTSC)/352*288(PAL) 60/50fps: 704*240(NTSC)/704*288(PAL) 30/25 fps: 704*480(NTSC)/704*576(PAL)</p> <p>240/200 fps version: 240/200fps: 352*240(NTSC)/352*288(PAL) 120/100fps: 704*240(NTSC)/704*288(PAL) 60/50 fps: 704*480(NTSC)/704*576(PAL)</p> <p>480/400fps version: 480/400fps: 352*240(NTSC)/352*288(PAL) 240/200fps: 704*240(NTSC)/704*288(PAL) 120/100 fps: 704*480(NTSC)/704*576(PAL)</p>
QUALITY	Select the recording quality for the specified channel. Options are: Network, Standard, High, Super or Ultra.
RECORDING	Assign the recording mode for each channel. Options are: Continuous, By Motion, By Sensor, By Schedule or Disable.
SENSOR RECORDING	Enable setting up to 4 sensors of 9 sensors for the specified channel.
PRE RECORD	Enable/disable pre-event recording. Pre-event recording time is 5 seconds and only intra-frames are recorded for pre-event recording.
POST EVENT RECORD	Set the post event recording time duration for the specified channel from 1 to 30 seconds.
AUDIO	Enable/disable audio recording for the specified channel.(Available from 1CH to 4 CH-Fixed)
SCHEDULE	Set the recording schedule. This menu item takes you to the Schedule Setup screen.

3-3-1. Quick record setting

User can setup all the values related with record such as Frame rate, quality, recording type, Pre-recording, and Post-recording on one page of setup screen.

1. Go to Record>Channel and press SEL button.



2. Then the bellow setup screen will pop up.




Figure 3.3.2. QUICK RECORD setup screen

3-3-2 Recording Schedules

To set up a recording schedule, select SCHEDULE in the RECORD menu. Use the arrow buttons to navigate through the items and set the recording.

[ALL]: Selected recording mode using the SEL button is applied to the entire time zone and all

channels.

[**SUN to SAT**]: Selected recording mode using the SEL button is applied to the entire time zone for the specified channel.

[**Vertical Bar “ | ”**]: Selected recording mode using the SEL button is applied to the entire channel for the selected time zone. Each vertical bar “ | ” corresponds to one hour.

[**- Individual Block of Time**]: Selected recording mode using the SEL button is applied to the selected 1-hour increment for the selected channel.

[**SEL**]: The recording mode can be selected using the SEL button.

[**COPY FROM to COPY TO**]: Setup values of recording mode for the selected channel can be copied for another channel setup.




Figure 3.3.2. Schedule recording setup screen

3-4. Setup – Device Mode

To set values for device, use the UP and DOWN controls to navigate through the menu items. Change the value of the menu item using the LEFT and RIGHT controls.





Figure 3.4.1. Device mode setup screen

Table 3.4.1. Menu items in Device Setup screen

Item	Description
ALARM OUT	Set the sensor, motion, and video loss for each alarm.
SPOT-OUT	Set the all details for spot monitoring.
PTZ	Set the PTZ camera speed, number, type and ID.
CHANNEL	Select specified channel for motion zone setup.
MOTION ZONE	Select Full Zone or Partial Zone for motion sensing.
MOTION SENSITIVITY	Set the motion sensitivity for the specified channel. Control the motion sensitivity from 1 to 9.
KEY TONE	Enable/disable key tone.
REMOTE CONTROL ID	Select an ID of remote control. 1. Select ID. 2. Press the same number as ID set in DVR on a remote control. 3. Then  icon will be displayed on Live screen of DVR that respond to the remote control.
SENSOR	Select sensor from 1 to 9(16).
TYPE	Set the type of sensor for the specified channel. Options are: None, N/O (normal open), and N/C (normal closed).

3-4-1. ALARM-OUT




Figure 3.4.2. ALARM-OUT setup screen

Table 3.4.2. Menu item in ALARM-OUT Setup screen

Item	Description
------	-------------

ALARM OUT	Select alarm from 1 to 4.
SENSOR IN	Enable setting up to 4 sensors of 9/16 sensors for the each alarm.
MOTION ON	Enable setting up to 4 cameras of 9/16cameras for the each alarm.
VIDEO LOSS ON	Enable setting up to 4 cameras of 9/16 cameras for the alarm.
ALARM DURATION	Set the dwell time of alarm from1 to 60seconds.

3-4-2. SPOT – OUT




Figure 3.4.3. SPOT-OUT setup screen

Table 3.4.3. Menu item in SPOT-OUT Setup screen

Item	Description
SPOT TYPE	Select either FULL or QUAD for spot channel display.
SPOT ON EVENT	Enable/disable spot channel display when event occurred.
SPOT EVENT DWELL TIME	Set the dwell time for the display of the event activated channel.
SEQUENCE	Enable/disable sequential display of spot channel in full screen.
SEQ-DWEL TIME	Set the dwell time for spot channel display in sequential display.
SPOT CHANNEL	Set the channel for spot monitoring.

3-4-3 PTZ Setup

To control the PTZ functions of the camera, connect the controller to the RS-485 port.




Figure 3.4.4. PTZ Control Setup Screen

Note: For speed dome cameras that support RS-485, connect them directly to the RS-485 port. If the camera is controlled with RS-232C, use an RS-485 to RS-232C signal converter.

On the PTZ control Setup screen, you can select or set the protocol of the camera that is the same as the one installed on the site. If the camera has a specific camera ID, select the camera ID using the LEFT and RIGHT arrow controls.

The following options are available on the PTZ control screen.

CHANNEL (channel number that the PTZ is connected to)

NAME (protocol type)

SPEED (19200, 14400, 9600, 4800, 2400)

ID (0-63)

3-4-4. Motion Zone Setup

When you select Partial Zone in the Motion Zone menu, you can set-up the motion sensing zones in the screen. To move around each rectangular zone, use the arrow controls. Press the SEL button on each rectangular zone you want to include as part of the motion sensing zone.

As you select each zone, the color changes. Press ESC button to return to the DEVICE menu.




Figure 3.4.5. Motion Zone selection screen

3-5. Setup – Storage Mode

Set the storage parameters in the Storage setup screen.




Figure 3.5.1. STORAGE setup screen

Table 3.5.1. Menu items in STORAGE Setup screen

Item	Description
------	-------------

OVERWRITE	When enabled, the DVR will continue recording and overwrite the oldest existing recorded data once the hard drive is full. When disabled, recording will stop once the hard drive is full.
DISK FORMAT	Format the hard drive. Use the UP and DOWN arrow buttons to select ON, then press SEL. You then have the option to YES or NO. Caution All recorder data will be lost. We recommend that you archive any data that you may need in the future before you format the hard drive.
DISK INFO	Hard drive information
RECORDING LIMIT	Enable/disable recording limit.
RECORDING LIMIT DAYS	Set the limit days for recording to the hard disk drive from 1 to 60 days.

3-6. Setup – System Mode

Use the System Setup screen to input system parameters.

Use the UP and DOWN arrow controls to navigate through the menu items and use the LEFT and RIGHT arrow controls to change the value of the menu items.







Figure 3.6.1. SYSTEM Setup Screen

Table 3.6.1. Menu items in SYSTEM Setup screen

Item	Description
DVR ID	<p data-bbox="450 318 783 349">Set the name of the DVR.</p> <p data-bbox="450 367 1406 539">Press the SEL button, use the LEFT and RIGHT or UP and DOWN arrow controls to navigate through the position for each alphanumeric character and Press SEL to apply the selected character. And Press OK to confirm the name.</p>  <p data-bbox="450 1037 1190 1068">SPACE / Caps Lock(Select either Capital or Lower letter)</p> <p data-bbox="450 1084 1378 1115">BS(Back space: Erase previous character) / Clear(Erase all characters)</p>
DESCRIPTION	<p data-bbox="450 1133 948 1164">Press SEL to view system information.</p> <p data-bbox="450 1180 1307 1211">(System version, storage capacity, IP address and MAC address.)</p> 
LANGUAGE	<p data-bbox="450 1706 783 1738">Set the desired language.</p>
DATE FORMAT	<p data-bbox="450 1760 1203 1792">Set the desired date and time display format. Options are:</p> <p data-bbox="450 1807 1070 1839">YYYY/MM/DD MM-DD-YYYY DD-MM-YYYY</p>
SET DATE&TIME	<p data-bbox="450 1856 1214 1888">Set the present date, time and daylight saving for the DVR.</p>



DATE & TIME

Set the present date and time for the DVR. Press SEL, then use the LEFT and RIGHT arrow controls to navigate through the position of each alphanumeric character in the date and time. Use the UP and DOWN arrow controls to change the selected character. Press ESC and select YES to confirm the new date and time.



DAY LIGHT SAVING

Set the DLS (Daylight Saving) for the area.

The options are:

USA

EU

Others

OFF.

1. USA (DLS time is applied automatically when being on the DLS time zone and is displayed on the current time)
2. EU (Set the GMT area for DLS time apply on the current time)
 - GMT AREA +00:00

3. OTHERS

- BEGIN (MAR/1ST/SUN/00H)
- END (SEP/1ST/MON/00H)


(Set the BEGIN and END time for the specific area except EU and USA) use the UP and DOWN arrow controls to change the value of month, week, day and hour.

CAUTION:

-Do not set the start time to 23:00 for DLS.

-DLS can't be applied, if the date of BEGIN and END is same.

SEND EMAIL Enable/disable SEND EMAIL function.



IP NOTIFICATION: Enable/disable sending daily e-mail reports on the status of your DVR.

EVENT ALARM: Enable/disable sending e-mail reports when event alarm occurs.

MAIL ADDRESS: Enter the appropriate email address to enable sending daily e-mail reports.

MAIL SERVER NAME: Enter the appropriate email server information to enable sending daily e-mail reports.

ID: Enter the ID of mail address.

PASSWORD: Enter the password of mail address.

RETURN MAIL ADDRESS: Enter the e-mail address for return email. When e-mail does not deliver or not work properly, the return email will be delivered to this e-mail address.

3-7. Setup – PASSWORD Mode

Use the LEFT or RIGHT and UP and DOWN arrow controls to set the password.





Figure 3.7.1. PASSWORD setup screen

Table 3.7.1. Menu Items in PASSWORD Setup Screen

Item	Description
ADMIN PASSWORD	Set the administrator password. After selecting this menu item you will be prompted for your current password and then the new password. Follow the prompts to change and confirm the new password.



The default password is 1111.

Use the arrow controls to change the password.

UP=1

RIGHT=2

DOWN=3

LEFT=4

Admin password is asked for the following functions.

Setup, Power, Search, and Key Lock from remote control.

USER PASSWORD

Set the user password. After selecting this menu item you will be promoted for your current password and then the new password.

Follow the prompts to change and confirm the new password.

The default password is 1111.

Use the arrow controls to change the password as described in ADMIN PASSWORD above.

User password is asked for the Search function.

NETWORK PASSWORD

Set the remote access password. You will need to enter this password when connecting to this DVR through the client software program. After selecting this menu item you will be prompted for your current password (the default password is 1111) and then the new password. Follow the prompts to change and confirm the new password. Use the arrow controls to change the password as described in ADMIN PASSWORD above.

3-8. Setup – Network Mode

Set up your network parameters on the Network Setup screen.




Figure 3.8.1. NETWORK setup screen

Table 3.8.1. Menu items in Network Setup screen

Item	Description
PORT	Port number (Default: 5445)
CLIENT ACCESS	Enable/Disable remote access through client software.
BANDWIDTH SAVING	Enable/Disable only key frame transmission. "ON" mode is favorable for use of low network bandwidth. Mostly, set "OFF" for normal use.
NETWORK TYPE	Set the type of network connection. Options are: LAN, DHCP, ADSL Note. Other parts of the Network Setup screen change depending on what network type you select.
DHCP	Sets to use HDCP (If this is selected, DVR automatically get IP varying from time to time from network.)
ADSL (PPPoE)	ID: Registered ID is necessary for ADSL connection. Password: Registered password is necessary for ADSL connection.
LAN	IP: Register IP address that is assigned for DVR. Gateway: Register Gateway that is assigned for DVR. Subnet Mask: Register Subnet Mask that is assigned for DVR.
DDNS	Enable/disable using domain name address through DDNS server. "ON" mode, DDNS server name appears for domain registration.

The DDNS sever name is **ns.standalone4ch.com**.

CAUTION: Do not change this sever name. If this is changed, the DDNS service cannot be used.

Registration

Check the MAC address of DVR from Setup>System>Description.

Please contact a distributor or an installer to register your DVR on a DDNS Server. Register the domain name on DDNS Server.

After the domain name and MAC address of the DVR are registered on a DDNS server, user can access the network with their own domain name.

3-8-1. Ports

When you connect one or more DVRs to a network through an IP sharing device, each device must have a unique TCP port number for access to each unit from outside the LAN. Also, the IP sharing device must be configured for port forwarding so when each port is accessed on the IP sharing device, it will forward to the appropriate DVR.

Note: This port number is listed next to the Port menu option in the Network Setup screen. If you plan to access the DVR units only from within the same LAN, the TCP port does not have to be changed.




Figure 3.8.1. Network setup screen - PORT

Network access beyond a router

In order to access the DVR remotely beyond a router (firewall), the user must open one TCP port for command level, live channels and storage channels. If this port is not opened properly, user can not access DVR beyond a router.

If the DVR port number is set to 5445, open the TCP port 5445 on the router.

3-8-2. Network Types

3-8-2-1. LAN

1. for the use of fixed IP. (See your network administrator if you do not have this information.)

2. When DVR is installed in IP sharer that is connected with ADSL, a user can assign fixed IP to DVR from IP sharer itself using “DMZ” function out of such sharer.

Input IP set in DMZ on “IP” field and Gateway of ADSL modem on “Gateway” field. Similarly, for Subnet Mask, DNS address, input relevant values in IP sharer.





Figure 3.8.2. Network setup screen - LAN

Table 3.8.2. LAN

Item	Description
IP	The fixed IP address of the DVR unit
GATEWAY	The IP address of the Gateway
SUBNET MASK	The subnet mask for the LAN



DNSThe address for the DNS server

3-8-2-2. DHCP

An IP address is automatically assigned by the DHCP server, which automatically assigns IP address and other parameters to new devices.

When ADSL or other network being used adopts variable IP method, not fixed IP. This option is used as a way to automatically get IP address.




Figure 3.8.3. Network setup screen - DHCP

3-8-2-3. ADSL (PPPoE)

To use this ADSL (PPPoE) function when the network type connecting the DVR is using PPPoE method.

If ADSL type is not using inputting IP and Password like VDSL or DVR is installed in IP sharer, a user can not select this function. In this case, a user should select DHCP or LAN.




Figure 3.8.4. Network setup screen - ADSL

Table 3.8.3. ADSL

Item	Description
------	-------------

ID	The user ID for the ADSL connection
PASSWORD	The password for the ADSL connection

3-8-3. Saving Setup of Network setup

After changing the network configuration, confirmation window will popup. To preserve the setup values that you have selected, select YES. Then system will reboot.




Figure 3.8.5. Network setup screen – SAVE SETUP

3-9. Setup - CONFIG Mode

User can control the configuration of DVR.





Figure 3.9.1. Config setup screen

Table 3.9.1. config setup


Item	Description
SAVE CONFIG	User can save the current configuration (Setting values) of DVR to the USB memory stick. Put the USB stick on the front panel and press SEL to start

the saving process.




LOAD CONFIG

User can upload the configuration of DVR to another DVR using the USB Memory stick. Put the USB stick on the front panel and press SEL to start the loading process.



LOAD DEFAULT


Select ON to reset the system to the default settings.



(Password, date format, DLS, Network setting, and HDD Overwrite will not be included.)

**LOAD
FACTORY
DEFAULT**

Select ON to reset the system to the factory default settings.



4. Saving Setup

To preserve the setup values that you have selected, select YES.



Figure 4.1.1. SAVE SETUP screen

5. Live, Search, and Playback

5-1. Live Viewing Screen

In the Live screen, video inputs from the cameras are displayed as they are configured in the Display Setup screen. Various on-screen display (OSD) symbols, which indicate the status of the DVR, are described in Table 5.1.1.













Figure 5.1.1. Live Viewing Screen

Table 5.1.1. Status Indicator Icons in Live Viewing Screen

Icon	Description
	Continuous recording in progress.
	Manual recording in progress. To set the Manual recording mode, press the Record button on the front panel.
	Motion alarm recording in progress.
	Audio mute. To set audio mute, press the Audio button on the front panel.
	Single audio display. To set audio single for highlighted channel only, press the Audio button on the front panel.
	Mixed audio display
	Indicates that alarm is set. To set the alarm function, press the Alarm button on the front panel.
	Indicates that alarm output is activated.
	Indicates that lock function for a remote control is set.



Alarm indicator. When there is an alarm (sensor or motion alarm) in the video channel, this icon will be highlighted bright red.




Indicates that a network client is connected to the DVR.



Indicates that sequencing mode is enabled.

Table 5.1.2. Button functions in Live Viewing Screen

Button	Description
	POWER ON/ OFF. If a password is set for power off, the system will ask for the password when the power button is pressed.
	Channel keys. For channel 10, press the 0 key. For channel 11, press the +10 and 1 key. For channel 16, press the +10 and 6 key.
SEQ	Enable/disable the automatic sequential display of channels in full screen, quad, 9-split display mode.
PTZ	Controls Pan/Tilt/Zoom operations.
SETUP	Launch the SETUP menu.
BACKUP	Press to capture video in jpeg format.
	Use the arrow controls when you want to move to next or previous channel and for number use when entering password. UP=1, RIGHT=2, DOWN=3, LEFT=4
	Switch between full, quad, 9 split and 16 split screen.
	Press to select audio mode such as SINGLE, MIX and MUTE. MUTE- All of 4 channels. SINGLE- Highlighted channel only. MIX- All of 4 channels.
	Enable/disable alarm operation.
	Perform continuous or manual recording for all channels.
	To enter into the SEARCH menu.



To exit from each menu.

5-2. SEARCH Screen

Press SEARCH in live mode to enter the Search screen.

When you press the Search button, DVR asks for a password as in Figure 5-2-1.




Figure 5.2.1. Search Screen

Enter the password using the arrow controls.

There are 7 ways of search menu such as TIMELINE, EVENT, GO TO FIRST TIME, GO TO LAST TIME, GO TO SPECIFIC TIME, LOG, and ARCHIVE on the screen.

5-2-1. TIME-LINE Search

The TIME-LINE search window is used to find the stored video by using the time line bar.




Figure 5.2.2. Time-line Search

1. Select the date of the video to begin searching by using the LEFT, RIGHT, UP and DOWN buttons to navigate through the days.
2. Once you have selected the date, press the SEL button to move to the time line search window.
3. Use LEFT / F/ADV or RIGHT/ F/REW buttons to select a time zone on the 24 hours time table.

Note: The recording mode is indicated on the screen as below.

C: Continuous-Green

M: Motion-Yellow

S: Sensor-Red

R: Manual -Purple

4. Once you have selected the time zone, press the SEL button to move to the 60 minutes time table.
5. Select All or a specific channel to search by using the UP and DOWN arrow buttons.
6. Once you select the channel, use the LEFT / F/ADV or RIGHT/ F/REW arrow buttons to move the time line select bar (blue) to the point you wish to start playing the video clip.
7. Press the SEL button to playback the recorded video.

5-2-2. Event Search

The Event Search window is used to find stored video. Three categories of search filters can be applied: DATE, CHANNEL and TYPE. Press SEL to select a value and move down to the next category and use the UP arrow button to move up to the categories you have previously entered. The ESC button will return the user to the previous screen.




Figure 5.2.3. Event Search screen

1. Select the date of the video to begin searching. Use the LEFT, RIGHT, UP, and DOWN buttons to navigate through the days.
2. Once you have selected the date, press SEL to move to the CHANNEL selector.
3. Use LEFT and RIGHT buttons to change the channel selection from ALL to any of the available channels.
4. Once you have selected the channel, press SEL to move to the TYPE selector.
5. Use the LEFT and RIGHT buttons to change the type of recording to ALL, MOTION, SENSOR, MANUAL, or CONTINUOUS.
6. Once you have selected the type of recording to search for, press SEL to produce a list of instances that fit your search criteria.
7. Use the UP and DOWN buttons to scroll through the on-screen listings.
8. Use the LEFT and RIGHT buttons to display a list of events that happened previous to or

after the current selection.

9. Once the desired event has been selected, press SEL to start playing back the selected video.
10. Press the BACKUP button to launch the archiving function in playback mode.

5-2-3. Go To First Time

You can access the oldest recorded data on the DVR hard drive by selecting GO TO FIRST TIME on the SEARCH window.

5-2-4. Go To Last Time

You can access the latest recorded data on the DVR hard drive by selecting GO TO LAST TIME on the SEARCH window.

5-2-5. Go To Specific Time




Figure 5.2.4. Go To Search Screen

You can search for video data from a specific instance by setting the date and time in the GO TO search window. Use the LEFT or RIGHT arrow buttons to move through the date and time values in this menu. Use the UP and DOWN arrow buttons to change the date and time value. Press SEL when the appropriate date and time is entered to playback the recorded video.

5-2-6. Log List Search

You can access the LOG list search screen by selecting LOG on the SEARCH window. Select a date and press SEL to open the LOG list from that date.




Figure 5.2.5. Log Search Screen

5-2-7. Archive Search

The ARCHIVE Search window is used to find previously stored video or images.

1. Select the date to begin searching by using the LEFT, RIGHT, UP and DOWN buttons to navigate through the days.
2. Once you have selected the date, press SEL to open the list of stored data.
3. Use the UP and DOWN buttons to scroll through the on-screen listings.
4. Use the LEFT and RIGHT buttons to display a list of stored events that happened previous to or after the current selection.
5. Once the desired event has been selected, press SEL to view the still image or the first frame of the selected video.
6. Press the BACKUP button to launch the archiving function in playback mode.



Figure 5.2.6. Archive Search Screen

5-3. Play mode

During playback of a recorded event, the mode changes from SEARCH to PLAY. While in PLAY mode, you may return to the SEARCH screen by pressing the ESC button.










Figure 5.3.1. PLAY Mode Screen

Table 5.3.1. Button functions in PLAY Mode

Button	Description
ESC 	Return to the previous menu screen, search window, or exit from the menu
	Press to rewind the footage at 1x, 2x, 4x, and 8x speeds. Reverse playback speed is shown as -1x(normal), -2x (2 times normal), -4x (4 times normal), and -8x (8 times normal) at the bottom right of the screen.
AUDIO 	Jump/Step backward. The playback position moves 60 seconds backward.
SEARCH 	Press to play or pause recorded video.
ALARM 	Jump/Step forward. Playback position moves 60 seconds forward.
	Press to fast forward the footage at 1x, 2x, 4x, and 8x speeds. Playback speed is indicated as +1x, +2x, +4x, and +8x for normal, twice, 4 times, and 8 times of the regular speed at the bottom right of the screen.
BACKUP	Press to launch the archiving function.

6. PTZ Control

To control the PTZ functions of the camera, press the PTZ button on the front panel.

Select the item you wish to control the PTZ camera and control them by using the UP and DOWN or LEFT and RIGHT buttons. Please refer to the table 6.1.1. for the control.



Figure 6.1.1. PTZ Control Screen

Table 6.1.1. Button Functions in PTZ Control

Item	Description
PAN / TILT	Use the UP or DOWN button for TILT and LEFT or RIGHT button for PAN of the selected camera.
ZOOM / FOCUS	Use the UP or DOWN button for ZOOM in or out and LEFT or RIGHT button for FOCUS near or far of the selected camera.
INITIALIZE	Initialize the PTZ settings of the selected camera.

Table 6.1.2. Description of RS-422/485 port

NO.	Description	
Classification	Rs-422	RS-485
1	TX+ (+ Transmit data)	
2	TX- (- Transmit data)	
3	RX+ (+ Receive data)	Data +
4	RX- (- Receive data)	Data -

7. Backup

7-1. Still Image backup onto USB flash memory or CD media

Still images can be captured and archived onto the USB stick, CD media or hard drive in live mode or while playing back recorded video.

In live mode, press the BACKUP button to launch the archive function.

1. When you press BACKUP button, the archiving screen will display as Figure 7.1.1.

2. And the DVR will ask which media you will take for archiving.
3. Once you select the media, the system will start to archive the data to the selected media.





Figure 7.1.1. Still Image Archiving and Backup Screen

7-2. Video backup onto USB flash memory or CD media

Video can be captured and archived onto the USB stick, CD media or hard drive while playing back recorded video.

In playback mode, press the BACKUP button to launch the archiving function.

1. When you press BACKUP button, the DVR will ask whether to archive a Still Image or Video clip.
2. If the user selects VIDEO, the DVR will ask which media you will take for archiving as Figure.
3. If the user selects VIDEO, the DVR will ask for the setting of the archiving duration.
4. Once you select the media, the system will start to archive the data to the selected media.






Figure 7.2.1. Video Archiving and Backup Screen

The DVR will convert the corresponding portion of the video into an AVI file.

7-3. Transferring still images or video from the ARCHIVE list

The stored data onto hard drive will be found in the ARCHIVE list in SEARCH menu.

User can back up still images or video into the storage device from the ARCHIVE list.

1. Select the date to begin searching by using the LEFT, RIGHT, UP and DOWN buttons to navigate through the days.
2. Once you have selected the date, press SEL to open the list of stored data.
3. Use the UP and DOWN buttons to scroll through the on-screen listings.
4. Use the LEFT and RIGHT buttons to display a list of stored events that happened previous to or after the current selection.
5. Once the desired event has been selected, press SEL to view the still image or the first frame of the selected video.
6. Press the BACKUP button to launch the archiving function in playback mode.




Figure 7.3.1. Archive Search Screen

7-4. Playback of Backup Video

7-4-1. Playback of backup video in AVI format

If the proper codec is not installed on your PC, the AVI file may not be played correctly. If this happens, install the 'FFDSHOW' codec that can download from open sites.

7-4-2. Playback of backup video in exclusive (NaFs) format

If the data is backed up in an exclusive file format, this video can be played back only on an exclusive player in CD that is provided with DVR.

8. Upgrading Firmware

In order to upgrade, the firmware upgrade file must first be downloaded and copied into the USB memory stick. Create a new folder in the USB memory stick and name it “upgrade”. Copy the firmware upgrade file “app16xxxxx.bin” for 16CH DVR or “app9xxxxx.bin” for 9CH DVR into the “upgrade” folder.

NOTICE

The folder on the USB memory stick must be named “**upgrade**”.

After the firmware upgrade is copied into the USB memory stick, connect the USB memory stick to the USB port on the front panel and do the following:

1. Press the SETUP button and enter the admin password.
2. Go to PASSWORD and select the ADMIN PASSWORD.
3. Enter the password as 12341234, and press the SEL button.
4. The engineering mode screen “DVR DIAGNOSTICS” will appear.
5. Select USB upgrade, and then the upgrading will start automatically.
6. After the upgrade is completed, select Boot Application to reboot DVR.




Figure 9.1.1. Engineering mode screen

9. Network – By an exclusive viewer

The DVR provides a live remote monitoring feature. Remote monitoring requires installation of a software client program on your PC.

NOTICE

In a high bandwidth network, a maximum of four users can access one DVR simultaneously. In a low bandwidth network it is recommended that only one user access the DVR at a time.

For remote viewing, the frame rate is limited to 1 frame/sec when there is no recording operation in the DVR. When the DVR is recording, the video frame rate for remote live monitoring will follow the recording frame rate on the DVR.




Figure 9.1. Main user interface

9-1. Overview

The remote software supports remote live viewing, search, playback and system configurations. By installing the Network Client Viewer on a Windows PC, you can monitor real-time and recorded images via optional Ethernet network.

9-2. Minimum PC requirements

PC Specification	Minimum Requirement	Recommended
CPU	Intel Pentium III 500Mhz	Intel Pentium IV 2Ghz
Memory	128MB	256MB
VGA	16MB	64MB
Resolution	1024x768	1024x768
Disk space	10MB	10MB
OS	Windows 2000	Windows 2000, Professional, XP Vista
Network	10/100Base T	10/100Base T
Others	Direct X 8.1	Direct X 9.0 or Higher

Before installing the program, check the PC specifications. The Network Client Viewer may not perform correctly if the PC does not meet the minimum requirements.

9-3. Installing the program

1. Insert the provided CD into the CD-ROM drive of your PC.



2. Run `network.exe` to start the installation process.


3. Follow the on-screen directions.



4. Double click the `Network Client` icon to start the program.

9-4. Live viewer



When installation is complete, double click the  icon on your desktop to start the program.





Figure 9.4.1. Main user interface

Table 9.4.1. Main controls in Live

NO	Button	Description
1	DATE & TIME	Displays the current date and time.
2	CONNECT	Click this icon to connect to the DVR
3	SEARCH	Click this icon to search for recorded video.

4	LOCK/ UNLOCK	Click this icon to lock/unlock all operations of the client software. Once the lock or unlock icon is clicked, this pop up window appears. Remember the password and enter it when you operate the client software.
5	PAN/TILT	Use these buttons to control the PAN/TILT features on the remote camera.
6	ZOOM/ FOCUS	Use these buttons to control the ZOOM/ FOCUS features on the remote camera.
7	CAPTURE	Click this icon to capture a still image. Once the capture icon is clicked, this pop-up window appears. The still image is captured in either jpeg or bmp file format.
		
8	PLAY/PAUSE	Click this icon to play/pause live video.
9	RECORD	Enable or disable recording of live video to local disk.
10	SETUP	Click this icon to setup configuration of client software.
11	EXIT	Click this icon to exit the client software.
12	DISPLAY MODE	Click these icons to select display mode.
13	AUDIO	Use the volume control bar to set the audio level. The audio can be turned on or off by clicking the audio icon.
14	HDD USAGE	DVR HDD storage Indicator.
15	ALARM	The alarm output indicator lights up for 5 seconds if alarm output is activated on the DVR.

9-5. Search and Playback Viewer

The search window can be accessed by clicking the search icon on the upper right of the main user interface.




Figure 9.5.1. Main user interface




Table 9.5.1. Main controls in Search


No	Button	Description
1	DATE & TIME	Displays the recording time of the data selected on the time bar at the bottom of the main user interface.
2	LIVE	Click this icon to see live video.

3 CAPTURE	Click this icon to capture a still image of recorded video. Once the capture icon is clicked, this pop up window appears. The still image is captured in either jpeg or bmp file format.
4 MARK IN	Click this icon to set the start time for video backup.
5 MARK OUT	Click this icon to set the ending time for video backup.
6 BACKUP	Click this icon to backup the selected recorded video in AVI format.
7 SEARCH CALENDAR	The calendar shows dates with recorded video in a light blue and the selected date in dark blue.
8 TIMELINE BAR	The timeline shows recorded data in dark blue on the bar. You can adjust the time-line scale and move it to the time you wish to play back. Click the play icon to display the recorded video.
9 PLAY BUTTONS	
10 DISPLAY MODE	Click these icons to select display mode.

9-5-1. Backup

You can back up recorded video in AVI format from the search viewer.

1. Click the MARK IN icon  when the scale on the blue timeline is on the time you wish to the backup file to begin.
2. Set the ending time on the blue timeline by dragging the scale to the ending time for the backup file and clicking the MARK OUT icon . The color of the timeline between the beginning time and ending time will change to dark green.
3. Next, click the backup icon  and the pop up window appears as below.



The beginning and ending time can also be set on this window.

After selecting a channel for backup, click the OK button. The backup will begin.

9-6. PC System configuration

Click the setup icon 

to setup the configuration of PC that the network client S/W is installed.

9-6-1. General

Once you click the setup icon, this pop up window appears. Select security options and set a password. When you access any of the selected functions, you will need to enter the password. You can also set the save path for capturing and backup.


Security Option: Set a password for security options.

Save Path: Specify the location to record the receiving video for Backup and still image for Capture.

Automatic reconnection: If a user selects this function, the client S/W will automatically try to connect to the previously connected IP address if the network connection is lost.


Display network statistics: If a user selects this function, the client S/W will display network status, Bit rate and Frame rate.

Time Format: Change the way the Client software displays the time.




9-6-2. Site

This option shows the channel information of the DVR and allows you to change the channel title.




9-6-3. Event

You can set event items, the amount of local disk space you want to allow and the save path for the log file.




- LOG – Select to save event log into 'log file'.
- ICON – Select to display the event on live video.
- EVENT LIST – Select to show the event in the 'Event List' window of live mode.

You can search and check the recorded log data.




9-6-4. Record

You can set the recording conditions for Always, Event, or Auto recording. You can also select individual channels or all channels to record.




When you set the recording condition to Event, you can set event for motion or alarm with duration. You can also set each or all channels to record.



9-6-5. Disk

You can select which local disk to use and the amount of disk space you want to allow the program to use for recording. You can also choose to overwrite data or stop recording when the maximum amount of disk space is full.



10. Network – By an web-browser viewer

The DVR provides a live remote monitoring feature by web-browser viewer.

10-1. Download Web Browser Viewer and Connection


1. User needs to access <http://ns.standalone4ch.com/webview2/> to get a web browser viewer. Then the window will appear as bellow. Click “YES” to download Web Browser Viewer from the server run by the manufacturer.




2. Web Browser Viewer will be downloaded and installed.



- Click **Connect** button and enter IP address (or Domain name using DDNS), the password, and Port number.



- Then user can access DVR.



10-2. Main Features

10-2-1. Live




Figure 10.2.1. Main user interface - Live

Table 10.2.1. Main controls in Live

No	Name	Description
1	DATE & TIME	Displays the current date and time.
2	CONNECT	Click this icon to connect to the DVR
3	SEARCH	Click this icon to search for recorded video.
4	LIVE DISPLAY MODE	Click these icons to select display mode.
5	PAUSE	Click this icon to pause the display screen.
6	CAPTURE	Click this icon to capture the image from live display.
7	SETUP	Click this icon to control remotely the setting of DVR.
8	PAN/TILT	Use these buttons to control the PAN/TILT features on the remote camera.
9	ZOOM/FOCUS	Use these buttons to control the ZOOM/ FOCUS features on the remote camera.
10	AUDIO	The audio can be turned on or off by clicking the audio icon.
11	CONNECTION STATUS	Shows the client connection information.

10-2-2. Search and Playback




Figure 10.2.2. Main user interface – Search & Playback

Table 10.2.2. Main controls – Search & Playback

No	Name	Description
1	DATE & TIME	Displays the current date and time.
2	Connect/Disconnect	Click this icon to connect to the DVR
3	LIVE	Click this icon to search for recorded video.
4	DISPLAY MODE	Click these icons to select display mode.
5	BACKUP	Click this icon to pause the display screen.
6	CAPTURE	Click this icon to capture the image from playback.
7	SETUP	Click this icon to control remotely the setting of DVR.
8	PLAYBACK BUTTONS	Use these buttons to control the PAN/TILT features on the remote camera.
9	SEARCH CALENDAR	Use these buttons to control the ZOOM/ FOCUS features on the remote camera.
10	Timeline Window	Search The audio can be turned on or off by clicking the audio icon.


APPENDIX

1. How to register DDNS (Dynamic Domain Name Server)

If DVR is installed in network using dynamic IP addressing and user want to access DVR with domain name instead of IP address, user should register DVR and domain name with DDNS.

1-1. Setting of NETWORK Setup menu

A. Please go to SETUP>NETWORK. There are three network types such as DHCP, ADSL, and LAN.



B. Please select proper network type and set DDNS as ON.

DHCP: Select when DVR is installed in Local Network with router or IP sharer and IP address is automatically assigned by the DHCP server.

LAN: Select when DVR is installed in Local Area Network with router or IP sharer and IP address is static and private IP address.


ADSL (PPPoE): To use this ADSL (PPPoE) function when the network type connecting the DVR is using PPPoE method.

If ADSL type is not using inputting IP and Password like VDSL or DVR is installed in IP sharer, a user can not select this function. In this case, a user should select DHCP or LAN.

C. Please make sure DNS SERVER NAME is “ns.standalone4ch.com”.

1-2. Checking Mac address on the rear panel of DVR and Registration No.

Please check the Mac address (Serial No.) and Registration No. on the rear panel of the system. Registration No. can be provided by manufacturer or distributor.



NOTE: If there is not registration No. on the system, please contact the distributor or manufacturer.

1-3. Registration at DDNS.


A. Please login <http://standalone4ch.com> and join member.




Enter an ID (which must be more than 4 and less than 12 characters, alpha and or numerical). Please check your ID with the “[check]” button to make sure the ID you choose is available. Choose your Password (which also must be more than 4 and less than 12 characters, alpha and or numerical). Confirm your (Password). Enter your Name and E-Mail address. The DDNS Service Administer will send a confirmation e-mail to the Subscriber’s e-mail address, so please

enter your e-mail address correctly.

B. Press Registration and register DVR as follows,



Input MAC Address and Registration that you checked from the rear of DVR. And input Domain Name and press [check] to see if Domain name is usable or not.



NOTICE

ID and password of registration DDNS is not the same as “Domain name”.

You may use alpha and numerical characters as well as hyphens for your Domain name. (i.e. [A~Z], [a~z], [0~9] or [-] for your domain name and it is case sensitive).

C. Press List and check the status of registration.




- ⊗ elapsed time since last update
- Less than 5 minutes
- ▲ 5 to 20 minutes
- More than 20 minutes
- ✗ No update history

Status	Specification
●	Elapsed time since last update is Less than 5 minutes
▲	Elapsed time since last update is more than 5 minutes and less then 20 minutes
●	Elapsed time since last update is more than 20 minutes
✗	No update history


2. Network access using Domain name

If DDNS registration is successful, you can access your DVR via the provided Network Client S/W.

A. Run Network Client S/W program and click the “connect” button.



B. Enter your domain name instead of IP address in the “IP Address” field.



C. Enter the Port no, Protocol and Password in each filed.

D. Press OK, then you can access to the remote DVR.