



MODEL NUMBER: XEA931-1-0-GB-XX

# ImproX MfT

## ImproX (MfT) Multi-function Terminal INSTALLATION MANUAL

### SPECIFICATIONS

<b>Working Environment</b> .....	Designed to work in an indoor (dry) environment similar to IP40. The Terminal is NOT sealed against water.	
<b>Input Voltage</b> .....	10 V DC to 30 V DC.	
<b>Power Requirements</b>	<b>Current (mA)</b>	<b>Power (W)</b>
Minimum Supply Voltage		
10 V DC .....	250	2.5
Maximum Supply Voltage		
30 V DC .....	83	2.5
<b>Third-party Port</b> .....	5 V DC ( $\pm 0.1$ V) at maximum 200 mA can be supplied to power Third-party Readers connected to the Port.	

*NOTE: The Current and Power Specifications (above) were made with no load on the Third-party Port.*

#### Relays

Relay Output .....	3 Relays, each with NO, COM and NC contacts.
Relay Contact Ratings .....	10 A at 28 V DC, 5 A at 220 V AC, 12 A at 120 V AC.

#### Digital Inputs

Type .....	4 Dry-contact inputs.
Protection Range .....	+50 V and -50 V continuous.

#### Terminal Installer Interfaces

Status Indicator	
Status LED .....	Blue LED (internally visible).

## Terminal Installer Interfaces

(Continued)

### Diagnostic Indicators

Incoming RS485 Data .... Flashing Green LED (internally visible).

Outgoing RS485 Data .... Flashing Red LED (internally visible).

## Antenna Reader (x2) Installer Interfaces

### Status Indicator

Status LED ..... Bi-colour, Red or Green LED.

### Buzzer

Volume and Tone ..... 4-Step adjustable volume, single tone.

# INSTALLATION INFORMATION

## Accessories

---

Find the following when unpacking the ImproX Multi-function Terminal:

- An ImproX MfT housed in a Black powder-coated Aluminium extruded Cabinet. The Cabinet consists of a Top Cover and Base, sealed at each end with a Mild Steel End Plate, secured with 8 Thread Cutter Screws (M3 x 8 mm).

**CAUTION: DO NOT use the Metal-oxide Varistors (25 Vrms, 500 A, 77 V max clamping) with mains power applications.**

- Three Metal-Oxide Varistors, 25 Vrms, 500 A, 77 V max clamping.
- A 3 V Lithium Battery (CR2032).
- Four Wood Screws (3.5 mm x 25 mm).
- Four Wall Plugs (7 mm).
- An extra Fixed Address Label.

## General

---

Remember the following when installing your ImproX MfT:

*NOTE: Where we specify a Remote Reader in this Manual, we imply that the same details apply to the Multi-mode Remote Reader.*

## Communications Distance

The RS485 communications distance between the ImproX Controller and the LAST ImproX Terminal in a cable run, MUST NOT exceed 1 km (1 090 yd). Achieve this by using good quality screened twisted 2-pair cable, earthed on one side.

Blank Space

## Termination Resistors for RS485 Bus Communications

Long transmission lines or multiple “star” connections, may cause communication problems. Placing the Termination Resistor Jumper Link (see Figure 3) in the LAST IMPROX MULTI-FUNCTION TERMINAL AT THE END OF THE CABLE RUN should solve the problem (depending on the bus).

## EARTH Connection

Connect the ImproX MfT to a good EARTH point. Using the RS485 Port, connect the EARTH Lead to the “SHD” Terminal. Mains EARTH can be used, but electrical noise may exist.

## Antenna Readers

### Antenna Reader Communications Distance

The ideal cable distance between the ImproX MfT and its Antenna Reader ranges between 2 m to 16 m (7 ft to 53 ft). Achieve this by using good quality screened, \*\*3-pair twisted cable. The cross-sectional area of the cable must not be less than 0.2 mm<sup>2</sup> (0.0003 in<sup>2</sup>).

*NOTE: \*\*When installing an ImproX RA, use 1-pair twisted cable.*

The cable specifications should be similar to the following:

Conductor Resistance:	< 2 ohms.
Capacitance, Core to Earth:	< 160 pF/m.
Capacitance, Core to Core:	< 100 pF/m.

### Distance between Antenna Readers from the SAME Terminal

To avoid mutual interference Install the Antenna Readers no closer than 150 mm (6 in) apart.

### Distance between Antenna Readers from DIFFERENT Terminals

To avoid mutual interference Install the Antenna Readers no closer than 500 mm (20 in) apart.

## Remote Readers

### Remote Reader Communications Distance

The distance between the ImproX MfT and the Remote Reader can be extended to a maximum of 10 m (33 ft) using a good quality shielded multi-strand 2-pair twisted cable. The individual conductor cross-sectional area of the cable must not be less than 0.2 mm<sup>2</sup> (0.0003 in<sup>2</sup>).

### Distance between Remote Readers from DIFFERENT Terminals

To avoid mutual interference, install the Remote Readers no closer than 500 mm (20 in) apart.

Blank Space

## Arc Suppression

Snubber devices are recommended for EMF Flyback and Arc Suppression when driving an inductive load with the Relay, see Figure 1.




Figure 1: EMF Flyback

## Installing the Battery

The Battery Holder is located in the top left-hand side of the ImproX MFT Terminals Printed Circuit Board (PCB), directly below the DIP-switch.

**Slide the 3 V Lithium Battery into the Battery Holder, from left to right, with the "+" symbol facing UP.**

## Mounting the Terminal

**CAUTION:** Make certain that you mount the Terminal on a vibration-free surface.

*NOTE:* Do not mount the Terminal with double-sided adhesive tape.

Select the mounting position of the ImproX Multi-function Terminal, considering accessibility and routing of wires.

Secure the Terminal to the mounting surface, using four suitable screws and wall plugs (supplied), nuts and bolts or rivets.

Blank Space

## Communication Link Settings




Communication Link Position	Setting
1.  See Figure 3 for orientation	Reserved
2. 	RS485
3. 	Reserved

Table 1: Communication Link Settings

## DIP-switch Settings (for the Third-party Port)




















Figure 2: Binary Details for the DIP-switch





		UHR900-0-1-GB-XX	UHR903-0-1-GB-XX	
	 Default	 ImproX RF/IR Receiver	 ImproX RF Button 1	 ImproX RF Button 2
Input 1	DOS #1	DOS #1	DOS #1	DOS #1
Input 2	RTE #1	RTE #1	RTE #1	RTE #1
Input 3	DOS #2	DOS #2	DOS #2	DOS #2
Input 4	RTE #2	RTE #2	RTE #2	RTE #2
A	-	-	-	-
B	-	Data Line	Data Line	Data Line
C	-	DOS #3	DOS #3	DOS #3
D	-	RTE #3	RTE #3	RTE #3
Relay 1	Reader #1	Reader #1	Reader #1	Reader #1
Relay 2	Reader #2	Reader #2	Reader #2	Reader #2
Relay 3	Bell Button	Reader #3	Reader #3	Reader #3

UHR903-0-1-GB-XX				
	 <b>ImproX RF Button 3</b>	 <b>ImproX RF Button 4</b>	 <b>ImproX RF Buttons 1 &amp; 2</b>	 <b>ImproX RF Buttons 3 &amp; 4</b>
Input 1	DOS #1	DOS #1	DOS #1	DOS #1
Input 2	RTE #1	RTE #1	RTE #1	RTE #1
Input 3	DOS #2	DOS #2	DOS #2	DOS #2
Input 4	RTE #2	RTE #2	RTE #2	RTE #2
A	-	-	-	-
B	Data Line	Data Line	Data Line	Data Line
C	DOS #3	DOS #3	-	-
D	RTE #3	RTE #3	-	-
Relay 1	Reader #1	Reader #1	Reader #1	Reader #1
Relay 2	Reader #2	Reader #2	Reader #2	Reader #2
Relay 3	Reader #3	Reader #3	Bell Button	Bell Button


	 <b>Magstripe ABA Track 2</b>	 <b>Barcode Code- 39 + checksum</b>	 <b>Barcode Code-39</b>	 <b>Wiegand 26/44/40/37 (Sagem MA100, MA200 or MA300)</b>
Input 1	DOS #1	DOS #1	DOS #1	DOS #1
Input 2	RTE #1	RTE #1	RTE #1	RTE #1
Input 3	DOS #2	DOS #2	DOS #2	DOS #2
Input 4	RTE #2	RTE #2	RTE #2	RTE #2
A	DOS #3	-	-	DOS #3
B	Clock Line	Data Line	Data Line	"0" Data Line
C	RTE #3	DOS #3	DOS #3	RTE #3
D	Data Line	RTE #3	RTE #3	"1" Data Line
Relay 1	Reader #1	Reader #1	Reader #1	Reader #1
Relay 2	Reader #2	Reader #2	Reader #2	Reader #2
Relay 3	Reader #3	Reader #3	Reader #3	Reader #3

Blank Space

	 <b>Open Wiegand</b>	 <b>Motor Lock</b>	 <b>Repeating (Pulse) Lock</b>	 <b>Fail Safe/Fail Secure Solenoid Lock</b>
Input 1	DOS #1	DOS	DOS	DOS
Input 2	RTE #1	RTE	RTE	RTE
Input 3	DOS #2	Locked	Locked	Locked
Input 4	RTE #2	Unlocked	Unlocked	Unlocked
A	DOS #3	-	-	-
B	"0" Data Line	-	-	-
C	RTE #3	-	-	-
D	"1" Data Line	-	-	-
Relay 1	Reader #1	Motor Lock	Pulse Lock	Solenoid Lock
Relay 2	Reader #2	Motor Lock	-	-
Relay 3	Reader #3	Bell Button	Bell Button	Bell Button

	 <b>ImproX Remote Reader (Single)</b>	 <b>ImproX Remote Readers (Dual)</b>	 <b>Motor Lock (With Dual ImproX Remote Readers)</b>	 <b>Repeating (Pulse) Lock (With Dual ImproX Remote Readers)</b>
Input 1	DOS #1	DOS #1	DOS	DOS
Input 2	RTE #1	RTE #1	RTE	RTE
Input 3	DOS #2	DOS #2	Locked	Locked
Input 4	RTE #2	RTE #2	Unlocked	Unlocked
A	Tx Line	Tx1 Line	Tx1 Line	Tx1 Line
B	Rx Line	Rx1 Line	Rx1 Line	Rx1 Line
C	DOS #3	Tx2 Line	Tx2 Line	Tx2 Line
D	RTE #3	Rx2 Line	Rx2 Line	Rx2 Line
Relay 1	Reader #1	Reader #1	Motor Lock	Pulse Lock
Relay 2	Reader #2	Reader #2	Motor Lock	-
Relay 3	Reader #3	Bell Button	Bell Button	Bell Button

Blank Space

	 <p><b>Fail Safe/Fail Secure Solenoid Lock (With Dual ImproX Remote Readers)</b></p>	<p><b>Summary of Abbreviations:</b></p> <p>DOS: Door Open Sensor.  RTE: Request to Enter or Exit.  Tx: Transmit.  Rx: Receive.</p>
Input 1	DOS	
Input 2	RTE	
Input 3	Locked	
Input 4	Unlocked	
A	Tx1 Line	
B	Rx1 Line	
C	Tx2 Line	
D	Rx2 Line	
Relay 1	Solenoid Lock	
Relay 2	-	
Relay 3	Bell Button	

**Table 2: DIP-switch Settings (for the Third-party Port)**

Blank Space



# ELECTRICAL CONNECTIONS

## Terminal Layout






Figure 3: Key Component Positions

# Connecting the ImproX MfT



**Figure 4: Typical Terminal, Relay and Antenna Connections**



**Figure 5: Typical Digital Input and Relay 3 Connections**





Figure 6: Typical Third-party Port Connections



**CAUTION:** When connecting a Remote Reader, the Tx Line from the ImproX Mft will go to the Rx Input of the Remote, and the Rx Line from the Remote, and the Rx Line from the Tx Input of the Remote (Tx to Rx and Rx to Tx).

**NOTE:** Only Remotes with Firmware versions 3.00 or above are compatible with the ImproX Mft. Older Remotes with Firmware versions 1.XX cannot be Firmware upgraded.

**NOTE:** Distance Between the ImproX Mft and the Remote Reader MUST NOT Exceed 10 m (33 ft).

**Figure 7: ImproX Mft Connected to two Remote Readers**

## Fixed Address Label

---

Once the ImproX MfT is installed, sketch a rough site plan. Attach the loose (additional Fixed Address Label packaged with the Terminal) Fixed Address Label in the position of the Terminal on the sketched site plan. When the system installation is complete and all the units are represented on the site plan by their Fixed Address Labels, file the site plan for future reference.

The ImproX MfT reports up to three Fixed Addresses.

Antenna 1's Fixed Address is the Fixed Address shown on the Fixed Address Label. Antenna 2's Fixed Address is calculated using the Antenna 1's Fixed Address +1. And the Third-party Readers Fixed Address is calculated using Antenna 1's Fixed Address +2.

When the Third-party Port is set up for two Remote Readers, their Fixed Addresses are as per Antenna 1's Fixed Address and Antenna 1's Fixed Address +1 respectively.

## GUARANTEE OR WARRANTY

**CAUTION: We reserve the right to nullify the products guarantee or warranty where you have not properly installed the Metal-oxide Varistors.**

This product conforms to our Guarantee or Warranty details placed on our Web Site, to read further please go to [www.impro.net](http://www.impro.net).

## USER NOTES

## USER NOTES



This manual is applicable to the ImproX (MfT) Multi-function Terminal,  
XEA931-1-0-GB-03.

(The last two digits of the Impro stock code indicate the issue status of the product).

XEA301-0-0-GB-08

Issue 09

Sep  
2007

ImproX MfT\English Manuals\LATEST ISSUE\  
ImprXMfT-insm-en-09.docx